


Model No. JR105D CORDLESS RECIPRO SAW



Model No.JR105D CORDLESS RECIPRO SAW

Položka	Objednávacie číslo	Popis	Zmena	ks	New/Old	Možnosť 1	Možnosť 2	Poznámka
001	165740-8	SHOE		1				
012	346526-1	CLAMPER		1				
013	251961-9	H.S.SET SCREW(FLAT POINT)M6X10		1				
014	310497-8	BLADE CLAMP		1	*			
014-1	310978-2	BLADE CLAMP	<	1				
015	256157-7	PIN 3		1				
016	266429-2	SKRUTKA 3X16MM		10				
017	183C31-3	HOUSING SET		1				
C10	263002-9	KOLÍK GUMA 4		3				
D10		INC. 45						
019	851J07-7	JR105D NAME PLATE		1	*			
019-1	851J06-9	JR105D NAME PLATE	<	1				
020	266747-8	PAN HEAD SCREW M4X14 WITH WM		3				
021	319060-4	GEAR HOUSING		1				
022	213961-7	O-KRÚŽOK 22 AC3600		1				
023	346525-3	PLATE		1				
024	443185-3	FELT SEAL		1				
025	313220-0	PÚZDRO TIAHLA JR100D		1				
026	313269-0	SLIDER N		1				
027	313270-5	COLLARED SLEEVE 4		1				
028	142284-5	GEAR COMPLETE		1				
029	211242-3	LOŽISKO GULIČKOVÉ 6902ZZ		1				
030	266747-8	PAN HEAD SCREW M4X14 WITH WM		2				
031	256158-5	KOLÍK 3 256158-5		1				
032	629165-5	DC MOTOR		1				
033	424467-2	KRYTKA JR100D		1				
034	632F46-0	SWITCH UNIT		1				
C10	620447-8	LED CIRCUIT		1				
035	644813-5	TERMINAL		1				
036	632F66-4	LINE FILTER UNIT		1				
037	453072-8	PÁČKA VYPÍNAČA JR100D		1				
038	233438-6	PRUŽINA 4 BDF/BHP		1				
039	454661-2	LOCK OFF LEVER R		1				
040	313219-5	PÁČKA JR100D		1				
041	256158-5	KOLÍK 3 256158-5		1				
042	141128-6	KRYT VYPÍNAČA JR100D		1				
043	319061-2	GEAR HOUSING COVER		1				
045	183C31-3	HOUSING SET		1				
C10	263002-9	KOLÍK GUMA 4		3				
D10		INC. 17						
046	234258-1	COMPRESSION SPRING 7		1				
047	253874-0	PODLOŽKA 4 9741/BO4900V		1				
048	922112-8	IMBUSOVA SKRUTKA 4x10		1				
049	285738-0	BEARING RETAINER 36		1				

Please order the parts with part number.

Print Date 8/10/2021

Model No.JR105D CORDLESS RECIPRO SAW

Položka	Objednávacie číslo	Popis	Zmena	ks	New/Old	Možnosť 1	Možnosť 2	Poznámka
050	265035-0	SKRUTKA SO ZAPUST. HLAV. M4x10		2				
051	424597-9	RUBBER RING 23		1				
A01	783201-2	INBUSOVÝ KLÚČ 3 783201-2		1				
A02	B-20432	LIST PÍLOVÝ 100MM		1				
A03	B-20404	RECIPROSAW BLADE 100MM		1				
A04B	456128-6	BATTERY COVER		1				
A04C	456128-6	BATTERY COVER		1				
A05B	***DC10SA	DC10SA BATTERY CHARGER		1	*			
D10		COMPO-PARTS			*			
A05C	***DC10SA	DC10SA BATTERY CHARGER		1	*			
D10		COMPO-PARTS			*			
A05-1B	***DC10SB	DC10SB BATTERY CHARGER	<	1				
D10		COMPO-PARTS						
A05-1C	***DC10SB	DC10SB BATTERY CHARGER	<	1				
D10		COMPO-PARTS						
A06B	197394-3	BATTERY BL1020B SET		2	*			
A06C	197402-0	BATTERY BL1040B SET		2	*			
A06-1B	197396-9	BATTERY BL1021B SET	<	2	*			
A06-1C	197406-2	BATTERY BL1041B SET	<	2	*			
A06-2B	197396-9	BATTERY BL1021B SET	O	2				
A06-2C	197406-2	BATTERY BL1041B SET	O	2				
A07B	821662-9	PLASTIC CARRYING CASE		1				
C10	162315-4	LATCH		2				
A07C	821662-9	PLASTIC CARRYING CASE		1				
C10	162315-4	LATCH		2				

Please order the parts with part number.

Print Date 8/10/2021