



Model XLT02Z Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	187889-4	HOUSING SET	1	PC.
	C10 263005-3	RUBBER PIN 6	2	PC.
	C20 803B00-9	CAUTION LABEL	1	
	C21 802J50-9	CAUTION LABEL	1	
	D10	INC. 40		
002	265995-6	TAPPING SCREW 4X18	8	PC.
003	815L76-4	XLT02 NAME PLATE	1	
004	643852-2	TERMINAL	1	PC.
005	263036-2	RUBBER PIN 5	1	PC.
006	268184-2	PIN 1.5	1	PC.
007	424026-2	CUSHION	1	PC.
008	450126-2	FR CHANGE LEVER	1	PC.
009	450125-4	SWITCH LEVER	1	PC.
010	631778-0	LED CIRCUIT	1	PC.
011	638885-0	SWITCH UNIT	1	PC.
012	265409-5	+ HEX. BOLT M5X30	1	PC.
013	152461-1	ANGLE HEAD COMPLETE	1	PC.
014	226720-0	ZEROL BEVEL GEAR 13	1	PC.
015	211064-1	BALL BEARING 6000	1	PC.
016	257660-1	SLEEVE 10	1	PC.
017	211061-7	BALL BEARING 6000LLB	1	PC.
018	961006-2	RETAINING RING S-10	1	PC.
019	962105-3	RETAINING RING R-26	1	PC.
020	257662-7	SLEEVE 15	1	PC.
021	261095-0	RUBBER WASHER 21	1	PC.
022	267120-5	FLAT WASHER 15	1	PC.
023	322689-7	ANVIL	1	PC.
024	322688-9	HAMMER	1	PC.
025	216001-0	STEEL BALL 3.5	22	PC.
026	267121-3	FLAT WASHER 20	1	PC.
027	233107-9	COMPRESSION SPRING 22	1	PC.
028	629846-1	DC MOTOR	1	PC.
029	267053-4	FLAT WASHER 12	1	PC.
030	226280-2	INTERNAL GEAR 69	1	PC.
031	257187-1	RING 32	1	PC.
032	226279-7	SPUR GEAR 29	1	PC.
033	226279-7	SPUR GEAR 29	1	PC.
034	154416-2	SPINDLE COMPLETE	1	PC.
035	216002-8	STEEL BALL 4.8	1	PC.
036	211064-1	BALL BEARING 6000	1	PC.
037	322719-4	WASHER 10	1	PC.
038	226279-7	SPUR GEAR 29	1	PC.
039	216002-8	STEEL BALL 4.8	1	PC.
040	187889-4	HOUSING SET	1	PC.
	C10 263005-3	RUBBER PIN 6	2	PC.
	C20 803B00-9	CAUTION LABEL	1	
	C21 802J50-9	CAUTION LABEL	1	
	D10	INC. 1		
042	424044-0	RUBBER RING 32	1	PC.
043	231990-8	RING SPRING 9	1	PC.

044	226721-8	ZEROL BEVEL GEAR 13	1 PC.
045	211131-2	BALL BEARING 6001DDW	1 PC.
046	324026-1	SPINDLE	1 PC.
051	231964-9	RING SPRING 7	1 PC.
052	962116-8	RETAINING RING R-28	1 PC.
A01	346449-3	HOOK	1 PC.
A02	251314-2	+ SCREW M4X12	1 PC.
D01	654069-2	RECEPTACLE	2 PC.
D02	654281-4	RECEPTACLE	2 PC.